

Drill-Free Solution

Ease of Installation for Sectional Mortise Locks!

- Use 4020 CW for Corbin Russwin and Best Single Cylinder Functions
- Use 4020T CW for Corbin Russwin and Best Single Cylinder w/Thumb Turn Model
- Use 9080 CW for Schlage Single Cylinder Functions
- Use 9050 CW for Schlage Single Cylinder with w/Thumb Turn Model
- Use 8255 CW for Sargent 8204, 8255, 8206 and other Single Cylinder Functions

Model	Size	Door
40 <mark>20 CW</mark>	5" × 12"	1-3/4"
4 <mark>020T CW</mark>	5" × 12"	1-3/4"
9 <mark>080 CW</mark>	5" × 12"	1-3/4"
9 <mark>050 CW</mark>	5" x 12"	1-3/4"
8255 CW	5" x 12"	1-3/4"
	5" x 12"	

Finishes: S/630 PB/605 BZ/612 10B/613





A good lock is not enough!

Available through your wholesale solutions provider today!

For further information, templates, cut sheets, vist us at don-jo.com